

	•			-		
POL	NUMBER: WP-11					
				Page 1 of 4		
PREPARED BY: Facilities Management (FM)		AUTHORIZED BY:	CLASSIFICATION: Work Procedure	EFFECTIVE: January 8, 2025		
		Monalehick		SUPERSEDES:		
	(****)	Andrew Konowalchuk		July 1, 2015		
APPLICATION:						
This work procedure shall be used in the following circumstances:						
1.	Removing all or part of a false ceiling to obtain access to a work area, if Asbestos- Containing Material (ACM) is likely to be lying on the surface of the false ceiling.					
2.	The removal or disturbance of $\leq 1 \text{ m}^2$ of friable ACM during the repair, alteration, maintenance or demolition of all or part of machinery or equipment or a building, aircraft, locomotive, railway car, vehicle or ship.					
3.	Enclosing friable ACM.					
4.	Applying tape or a sealant or other covering to pipe or boiler insulation that is ACM.					
5.	Installing or removing ceiling tiles that are ACM, if the tiles cover (≥7.5 m ²) and are installed or removed without being broken, cut, abraded, ground, sanded or vibrated.					
6.	Breaking, cutting, drilling, abrading, grinding, sanding, or vibrating non-friable ACM if the material is not wetted , and the work is done only by non-powered hand-held tools.					
7.	Removing \geq 1m ² of drywall where joint filler compounds that are ACM have been used.					
8.	Breaking, cutting, drilling, abrading, grinding, sanding, or vibrating non-friable ACM if the work is done by means of power tools attached to a HEPA dust collector.					
9.	Removing ACM pipe or duct insulation or similar structure using a glove bag.					
10.	Cleaning or removing filters used in air handling equipment in a building that has sprayed fireproofing that is ACM (see <u>WP- 57</u>).					
11.	Working in close proximity to friable asbestos where the asbestos is likely to be disturbed during the performance of the work.					
12.	Application of any co	overing or sealant to pipe	e or other thermal insulation co	ontaining asbestos.		
13.	Any operation that is asbestos.	s not classified as Type 1	or Type 3 operation but may	expose a worker to		
It is the responsibility of the worker involved to decide if the work they are doing is in agreement with the above criteria for this work procedure. If any doubt exists, the worker shall refer the matter to their supervisor for a decision.						



Facilities Management

POLICY:

O REGULATION 278/05 - TYPE 2 OPERATIONS

NUMBER: WP-11

Page 2 of 4

NOTIFICATION OF OCCUPANTS:

All occupants of the work area, or the room in which the enclosure is to be erected, must be notified that work involving the possible disturbance of friable asbestos is necessary, what kind of work is being done, and the length of time the enclosure would be required. If the work will require less than four hours of disruption, the onus of notification belongs to the worker. For longer periods, the worker's supervisor will arrange a more formal notification.

PREPARATION OF WORK AREA:

- 1. Shut down and isolate all ventilation serving the work area. Seal all ventilation openings with plastic.
- 2. Remove all furnishings and equipment from the work area, where practical. This should include anything that the occupants may wish to use during the work period. Where this is not practical, cover with 6 mil. polyethylene and seal.
- 3. Erect a portable enclosure to seal the work area using 6 mil. polyethylene sheeting. Entrance to the enclosure shall be through a double overlapping flap of 6 mil. polyethylene. Both carpeted and hard surface floors require a single layer of 6 mil. polyethylene sealed to the enclosure.
- 4. Post applicable warning at the entrance(s) to the work area, and directly on the flap door of the portable enclosures.

WORKER PROTECTION:

- 1. All individuals entering the enclosure must wear approved respirators (and have an active fit test certification, where required) and disposable coveralls with head cover.
- 2. Disposable coveralls and work boots shall be HEPA vacuumed, or wet wiped, before leaving the enclosure.
- 3. After leaving the enclosure, individuals shall thoroughly wash their hands and face at the nearest washroom.

WORK PROCEDURE:

- 1. All tiles removed from the ceiling shall be HEPA vacuumed and covered with plastic.
- 2. Any friable asbestos lying in the area of the work, and which may be disturbed during the work, shall be cleaned up by HEPA vacuuming or wet wiping before commencing any work.
- 3. If any asbestos is to be removed, it shall be thoroughly wetted with amended water before removal.
- 4. Exposed edges of asbestos, resulting from removal, shall be sealed with an approved spray adhesive made for this specific purpose.
- 5. Frequently, and at regular intervals during the work, dust and waste containing asbestos in



Facilities Management

POLICY:

O REGULATION 278/05 - TYPE 2 OPERATIONS

NUMBER:

WP-11

Page 3 of 4

the work area shall be cleaned up by wet wiping and placed in 6 mil. polyethylene bags, or shall be cleaned up by HEPA vacuuming (after large pieces of asbestos and/or materials containing asbestos are picked up).

'CLEANUP:

- 1. At regular intervals during the work, and upon completion, asbestos-containing dust and bagged waste shall be cleaned up using a HEPA filtered vacuum, or by wet wiping.
- 2. All tools and equipment used inside the enclosure shall be HEPA vacuumed before removal.
- 3. The complete floor area shall be HEPA vacuumed before the removal of the enclosure.
- 4. All material for disposal shall be placed in approved, labelled bags, which shall be HEPA vacuumed or wet wiped before removal from the work area. Waste shall be doubled bagged, with one yellow and one clear bag. Each bag shall be sealed separately.
- 5. Plastic sheeting shall be wetted before removal and disposal. Rigid and portable enclosures to be reused shall be thoroughly cleaned by HEPA vacuuming or wet wiping.
- 6. When protective clothing is to be disposed of, it shall be decontaminated, as above, and double bagged in 6 mil. polyethylene bags (yellow and clear bags) that are sealed separately.
- 7. All material for disposal is to be sealed in 6 mil. bags, labelled to indicate contents, and taken to the Support Services Building for holding until ultimate disposal.

ASBESTOS WORK HOURS REPORT:

1. Worker shall report hours of work for all Type 2 Operations to employer to meet reporting obligations as per Reg. 278/05, Section 21.

GENERAL PRECAUTIONS:

- 1. A wetting agent shall be added to the water required to be used by this work procedure to improve its capability to control the spread of asbestos dust.
- 2. No eating, drinking, chewing, or smoking is allowed in the work area.
- 3. Compressed air shall not be used to clean up, or remove asbestos, from any surface.

DEFINITIONS:

False Ceiling ______Any suspended ceiling, all of, or part of, which is removable. (Includes access openings to non-removable ceilings.)

Friable Asbestos ______Asbestos containing material that can be crumbled, pulverized, or powdered, including that which has been crumbled, pulverized, or powdered.



Facilities Management

POLICY: O REGULATIOI	NUMBER: WP-11				
		Page 4 of 4			
Ventilation	entilationAll air-handling systems moving air into, or out of, or within the work area.				
Isolation	Sealing off of a duct to prevent airflow into, or out of,	the work area.			
Amended Water	ater to which a wetting agent has been added to improve its capability control the spread of dust.				
HEPA Vacuum	A vacuum cleaner equipped with a High Efficiency Pa to trap very small asbestos particles.	articulate Air filter			
Asbestos Awareness (Comprehensive) training must be completed every 3 years.					
Western University Respiratory Protective Equipment Program					
 <u>https://www.uwo.ca/hr/form_doc/health_safety/doc/policies/respirator_policy.pdf</u> 					
WP-57: Cleaning or Removing Building Filters Containing Asbestos Fireproofing					
 <u>https://uwo.ca/fm/pdf/policies/work_procedures/WP-</u> <u>57_Cleaning_or_Removing_Bldg_Filters_Containing_Asb_Fireproofing.pdf</u> 					